

Page 1:

LOGO With Products pictures

Kit contains:

1x Classic 900mAh battery 1XCE8 Tank 1XUSB 1xMetal case

Page 2:

Battery:

The battery get a "lock" feature, to stop unexpected activation when not in use.

Press the button 5times within 2secs can turn on the battery, to turn off the battery press the battery 5times within 2Secs again.

White Led light shows 80%-100% power.

Blue led light shows 40%-80% power left

Red led light shows power less than 40%

Battery charging:

To avoid damage, under normal conditions, it takes about 2-2.5 hours to charge the battery. The Classic kit battery has a microchip to prevent overcharging. The Battery LED will flash 3times when you plug it on the USB. Then the LED will flash Red when power under 40%, Blue LED when Power is under 80%, over 80% charged LED will be White, when fully charged, LED keeps white but USB light will turn green

To charge battery, gently connect the battery threads to the USB line. Plug USB cable into a Adaptor (DC4.2V-420MA) or a computer. When using a computer to recharge, **you should use ONLY the dedicated USB charger provided to avoid damaging Battery or Personal Items, Use of other Chargers can cause the Battery to Explode and cause Fire.** Charge the battery fully before using to maintain a good battery life.

The battery fully charged before it is sent it out from manufacture.

CE8 tank

The CE8 tank uses a mesh system which will avoid burning taste and create huge vapor .with 2.0ml liquid and wickless.

If the Clearomizer overheats, wait until it returns to a normal temperature before using again. If the heating element in the Clearomizer is dry, it will produce a burning taste no matter if it's mesh system or normal system. Please ensure there is enough liquid in the Clearomizer to prevent heating element from drying. Please notice that when the vapor become obviously less, please change the Clearomizer to a new one or change the heating coil to a new one.

Liquid

E-Liquid: DO NOT DRINK!

Clean excess liquids from around the refill area before using .If you get excess liquids on your lips from the Clearomizer, wipe area immediately or wash your mouth with water. Do not drink liquids. **Use Imperial E-Liquids for best Results.** Keep liquids in a cool safe place away from

children and pets. Do not store in a hot place or in direct sunlight. Do not store in a cold place to prevent freezing. Improper storage will cause e-liquid to spoil or lose flavor.

How to assemble and use your Classic kit:

Picture

Screw CE8 Tank with e-liquid into the battery, but not too tight, 5 clicks to turn on battery, and press the button while inhaling, then release. Battery has short circuit protect function, it will cut off automatically if inhaling over 10 seconds. After ash alarm, can be use normally.

Maintaining Product

Always charge the battery fully before using to maintain a good battery life. To ensure a good battery life, do not store battery in a hot or humid environment. Do not drop battery. Do not force battery. **Keep battery away from heat or sharp objects.** Maintaining this product, will ensure proper function, you should use as directed and clean regularly. Be careful not to let dust settle in Clearomizer and battery component.